

Installation Instructions

1312100 LED Low Profile Universal Plow Light Kit

Patent Pending

Preliminary Steps


- 1. Read all instructions carefully and study diagrams before installing lights.
- 2. Check with state and local authorities for laws governing usage and proper mounting of auxiliary lamps.
- 3. Disconnect ground connection from battery (marked "-") to avoid accidental short circuits before attempting to connect electrical wires.
- 4. Route new wires along existing wiring tape as necessary to correct slack.
- 5. When running wires through the firewall, keep them away from moving parts.

Mounting Lights


- 1. Drill 8.5 mm holes for screw placement on the surface where you would like to fix the light.
- 2. Use the bolts to fasten the lamp, add the locking washer and tighten the bolt.
- 3. This headlight should be fitted symmetrically, one on both sides of the application respectively.
- 4. After installation is completed successfully, make sure the lights' direction is as shown below:


Warning:

- 1. Work under the specified voltage (DC10-30V)
- 2. This head light includes 5 functions: high beam, low beam, park light, indicator light, and heating function.
- 3. Wiring requirements:



- 4. The heating function will work automatically when the light is on. When the temperature of the interior of the light reaches 122°F the heating function will stop working automatically.
- 5. This light become hot under continuous use. Do not remove or touch the casing for at least 30 minutes after turning the lamp off.
- 6. Keep heat-sink clean and exposed to maintain airflow.





WARRANTY

Buyers Products Co. warrants all truck/trailer hardware manufactured or distributed by it, to be free from defects in material and workmanship for a period of one year from date of shipment. Parts must be properly installed and used under normal conditions. Any product which has been altered, including modification, misuse, accident or lack of maintenance will not be considered under warranty. Normal wear is excluded. The sole responsibility of Buyers Products Co. under this warranty is limited to repairing or replacing any part or parts which are returned, prepaid, and are found to be defective by Buyers Products Co. Authorization from Buyers Products Co. must be obtained before returning any part. No charges for transportation or labor performed on Buyers' products will be allowed under this warranty.