

8883010 Rear Observation System With License Plate Night Vision Camera



Table of Contents

| What's in the Box? | 3 |
|-------------------------------|-------|
| Introduction | 4 |
| Safety Information | 5-6 |
| Before Beginning Installation | 7-8 |
| Installation Guide | 9-10 |
| Installing Monitor | 11-12 |
| Installation Diagram | 13 |
| Remote Control Diagram | 13 |
| Monitor Specifications | 14 |
| Camera Specifications | 15 |
| Troubleshooting | 16 |
| Warranty | 17 |
| Disclaimer | 18 |

What's in the Box?

| QTY. | Part Included in Kit | Replacement Part |
|------|---|---------------------|
| 1 | Color CCD Infrared Weather Resistant Camera | 8883102 |
| 1 | 7" TFT LCD Color Monitor with Stan- dard U-Bracket Mount, Pedestal Mount, Flush Mount | 8883300 |
| 1 | Sun Shade | - |
| 1 | 65' Camera Cable | 8883165 |
| 1 | Power Harness | - |
| 1 | Remote Control | - |

Accessories

8883116- 16' Camera Cable

8883132- 32'Camera Cable

8883165-65' Camera Cable

8883182- 82' Camera Cable

8883101- Standard Camera

8883103- Recessed Bullet Camera

8883104- Side Surface-mount Camera

8883105- Sphere Surface-mount Camera

8883108- Dual Camera

Introduction

Please read all of the installation instructions carefully before installing the product. Improper installation will void manufacturer's warranty.

Congratulations on purchasing a Rear Observation System With Night Vision Camera. With this manual you will be able to properly install and operate the unit.

The Rear Observation System is intended to be installed as a supplement aid to your standard rear view mirror that already exists in your vehicle. The Rear Observation System should not be used as a substitute for the standard rear view mirror or for any other mirror that exists in your vehicle.

In some jurisdictions, it is unlawful for a person to drive a motor vehicle equipped with a TV viewer or screen located in any location that is visible, directly or indirectly, to the driver while operating the vehicle.

Safety Information

Please read the entire manual and follow the instructions and warnings carefully. Failure to do so can cause serious damage and/or injury, including loss of life. Be sure to obey all applicable local traffic and motor vehicle regulations as it pertains to this product. Improper installation will void manufacturer's warranty.

USAGE

- The Rear Observation System is designed to help the driver safely detect people and/or objects helping to avoid damage or injury. However, you the driver, must use it properly. Use of this system is not a substitute for safe, proper or legal driving.
- Never back up while looking at the monitor alone. You should always check behind and around the vehicle when backing up, in the same way as you would if the vehicle did not have the Rear Observation System. If you back up while looking only at the monitor, you may cause damage or injury. Always back up slowly.
- The Rear Observation System is not intended for use during extensive back-up maneuvers or backing into cross traffic or pedestrian walkways.
- Please, always remember, the area displayed by the Rear Observation System is limited. It does not display the entire panorama that is behind you.

Safety Information

- Electric shock or product malfunction may occur if this product is installed incorrectly.
- Use this product within the voltage range specified.
 Failure to do so can cause electric shock or product malfunction.
- Take special care when cleaning the monitor.
- Make sure to firmly affix the product before use.
- If smoke or a burning smell is detected, disconnect the system immediately.
- Where the power cable may touch a metal case, cover the cable with a friction tape. A short circuit or disconnected wire may cause a fire.
- While installing the Rear View System be careful with the wire positioning in order to avoid wire damage.
- The Rear View System should only be used when the vehicle is in reverse.
- Do not install the monitor where it may obstruct drivers view or obstruct an air bag device.
- Dropping the unit may cause possible mechanical/ electrical failure.

Before Beginning Installation

Before drilling please check that no cable or wiring is on the other side of the wall. Please clamp all wires securely to reduce the possibility of them being damaged while vehicle is in use. Keep all cables away from hot or moving parts and components causing electrical interference.

We recommend doing a bench test before installation to insure that all components are working properly (pg 13).

Step 1: Choose the monitor and camera locations.

Step 2: Install all cables in vehicle, when necessary a 0.8" (20mm) hole should be drilled for passing camera cable through vehicles walls. Install split grommets where applicable.

Step 3: Once all cables and wiring have been properly routed, perform a system function test by temporarily connecting the system. If the system seems to not be operating properly see troubleshooting (pg 17).

Before Beginning Installation

Cable

- 1. Be sure to route the cable carefully. The camera cable uses aircraft grade connectors which means the camera cable can be exposed to all weather elements. Do not run the cable over sharp edges, do not kink the cable and keep away from HOT and rotating parts, such as but not limited to, exhaust systems and drive shafts.
- 2. Fasten and secure all excess cable.

Monitor

- To Attach the Pedestal mount to the dashboard or to the headliner/roof using self-tapping screws and/or the adhesive pad.
- 2. Attach monitor to mount, and adjust mounting angle to allow optimum driver viewing comfort. (see figure on page 11)

Camera

- 1. Camera plug will require a minimum of a 5/8" opening or hole to be fed through. If none exist, find and mark location to drill hole for plug. Be sure there are no wires or obstructions behind marked location.
- 2. Deburr hole.
- **3.** Feed plug and cable through the hole.
- **4.** Secure camera to license plate mounting hole locations using existing mounting hardware.
- Adjust camera angle by loosening set screws with a 1.5mm allen key. Once desired angle is found, tighten set screws.

Installation Guide

The Power Harness

- To power the system connect the power (RED) +12VDC wire to ignition power and the ground (BLACK) wire to chassis ground.
- These are the only wires needed to power the entire system and all the cameras. Each camera can be seen at any time by simply pressing the power button and using the V1/2 button to toggle.
- The three positive trigger wires (CH1, CH2, CH3) each represent one channel and will turn on their channel when the trigger wire is energized with +12VDC.
- Camera 3 is the designated backup channel. To have the backup camera come on when you go into reverse, connect the CH3 wire to reverse power (or any power source that comes on only in reverse).
- The other channels can similarly be triggered (i.e. side cameras can be triggered by the turn signals etc.)
- To automatically have camera and monitor turn ON when vehicle activates, simply twist CH3 positive trigger +12VDC to Red Power line +12VDC and wire to ignition power.

Note: This setup will disable the menu in channel 3. To access the menu simply move to channel 1 or 2 and all the changes will apply to channel 3.

Note: When the channel 3 wire is active it will have precedence over the other triggers. Therefore, if you wish to use multiple triggers, do not attach the blue trigger to constant power.

Installation Guide

- Audio: There is audio on channels 2 and 3. On CH3 the trigger wire must be energized (+12VDC) to activate the audio. On CH2 the audio is always on.
- Grid-lines: The grid-lines are also carried through the CH3 wire. To use the grid-lines for reversing, connect the CH3 wire to a reverse power. Grid lines can be deactivated in the menu. Menu > PARKSET > Toggle ON or Toggle OFF
- There is a built-in voltage regulator for our systems which can handle 10-30 Volts DC.


Note: Included camera does not have built in microphone.


Note: The camera and monitor can always be activated by manually pushing the power button on monitor. This is in addition to utilizing the positive triggers.

Note: If connecting power directly to battery, the camera is always ON and therefore can drain battery. Therefore it is recommended to connect power to an ignition switched accessory power source.


Standard U-Bracket Monitor Installation

 Remove the thumb and allen screw from the monitor then remove monitor. Place bracket in desired location and fasten down with 3 screws. (See below pictures)







2. Using the thumb and allen screws put the monitor into the bracket, adjust angle, and lock it. (See below pictures)





3. Finish installation. The adjustable angle is 30° forward or backward. (See below pictures)






Optional Monitor Installations

Pedestal Mount

 Using screws, secure pedestal bracket. (See below pictures)



Secondly, slide the metal buckle piece on the top of the pedestal bracket into the notch on the back of the monitor. Move the bracket to the desired location and tighten. (See below pictures)






Flush Mount



Installation Diagram





6. Mode select

4. Menu

Monitor Specifications



¹⁰ 7" monitor

- 1. "-"
- 2. Menu
- 3 "+"
- 4. Power
- 5. Channel 1
- 6 Channel 2/Channel 3
- 7 Mode
- 8. Remote control window
- 9. A/V input connector
- 10. Bracket knobs

| Screen size | 7 inch |
|-----------------------|--|
| Aspect ratio | 16:9 |
| Resolution | 800x480 |
| Brightness | 500cdm |
| Audio & Video | 2 Ways video input (3 Ways video input optional) |
| | 3 Ways audio input 1 AV input (optional) |
| Video System | PAL & NTSC automatically |
| Voltage | 12V-24V |
| Power Consumption | 5W |
| Impact Rating | 5G |
| Language | Multi-language |
| OSD Menu | Display Menu, Brightness, Color, Contrast |
| | Adjustable |
| Built-in speaker | Yes |
| Bracket accessories | U Type Bracket, Pedestal Bracket, Recessed |
| | Mount |
| Sunshade | Removable |
| Operation Temperature | -4°F ~ 167°F |

Camera Specifications

| Sensor | 1/4 CMOS |
|-----------------------|--------------------------|
| Resolution (PAL) | 656 (H) x 492 (V) pixels |
| TV Line | 420 TV Line |
| Lens | 2.8mm |
| View angle | 120° |
| Infrared distance | 45ft (8pcs Infrared LED) |
| Min illumination | 0.1 Lux (LED ON) |
| S/N Ratio | 52dB |
| Video output | 1Vp-p 75Ω |
| Water Resistant | IP68 |
| Impact Rating | 20G Vibration/10G shock |
| Operation Temperature | -4°F ~ 167°F |

Troubleshooting

Monitor Displays Blue Screen & Displays "No Signal"

- Do a hard reset, unplug all cables and power cables, leave out for 1 minute, and then re-connect.
- Check to ensure that the connection to the camera is tight.
- Verify camera cable is plugged into camera port
- Verify that the trigger on power harness is put to power +12VDC.
- If the problem still persists, verify that alternate ports work. If alternate ports do not work, remove trigger wire from +12VDC and select alternate channels.

Monitor Will Not Power-Up (no backlight on power)

- · Check fuse
- Check +12VDC connection
- Check ground connection
- Try power and ground direct to battery

No Image On Screen

- Verify camera is on correct camera input
- Verify cable is connected to monitor
- Verify camera is connected to cable
- Connect known working camera and cable to monitor.
- Verify trigger source is supplying power

Audio on Camera

- Verify chosen camera has audio
- Verify volume setting
- Confirm that the CH3 trigger is connected to +12VDC

Warranty

Two Year Warranty

Buyers Products Company, Inc. warrants this product against material defects for a period of two years from date of purchase. We reserve the right to repair or replace any such defective unit at our sole discretion. Buyers Products Company, Inc. is not responsible for a defect in the system as a result of mis-use, improper installation, damage or mishandling of the electronic components. Buyers Products Company, Inc. is not responsible for consequential damages of any kind.

This warranty is void if: defects in materials or workmanship or damages result from repairs or alterations which have been made or attempted by others or the unauthorized use of nonconforming parts; the damage is due to normal wear and tear, this damage is due to abuse, improper maintenance, neglect or accident; or the damage is due to use of the Buyers Products Company, Inc. system after partial failure or use with improper accessories.

Warranty Performance

DURING THE ABOVE WARRANTY PERIOD, SHOULD YOUR Buyers Products Company PRODUCT EXHIBIT A DEFECT IN MATERIAL OR WORK-MANSHIP, SUCH DEFECT WILL BE REPAIRED WHEN THE COMPLETE Buyers Products Company, INC. PRODUCT IS RE-TURNED, POSTAGE PREPAID AND INSURED, TO Buyers Products Company, INC. OTHER THAN THE POSTAGE AND INSURANCE REQUIREMENT, NO CHARGE WILL BE MADE FOR REPAIRS COVERED BY THIS WARRANTY.

Warranty Disclaimers

NO WARRANTY, ORAL OR WRITTEN, EXPRESSED OR IMPLIED, OTHER THE ABOVE. WARRANTY IS MADE WITH REGARD TO THIS Buyers Products Company, INC. DISCLAIMS ANY IMPLIED WARRANTY OR MERCHANT-ABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE AND ALL OTHER WARRANTIES IN NO EVENT SHALL Buyers Products Company. INC. LIABLE FOR ANY INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES OR FOR ANY COSTS, ATTORNEY FEES, EXPENSES, LOSSES OR DELAYS ALLEGED TO BE AS A CONSEQUENCE OF ANY DAMAGE TO, FAILURE OF, OR DEFECT IN ANY PRODUCT INCLUDING, BUT NOT LIMITED TO, ANY CLAIMS FOR LOSS OF PROFITS.

Disclaimer

Buyers Products Company and/or its affiliates does not guarantee or promise that the user of our systems will not be in/part of an accident or other-wise not collide with an object and/or person. Our systems are not a substitute for careful and cautious driving or for the consistent adherence to all applicable traffic laws and motor vehicle safety regulations. The Buyers Products Company products are not a substitute for rear view mirrors or for any other motor vehicle equipment mandated by law. Our camera systems have a limited field of vision and do not provide a comprehensive view of the rear or side area of the vehicle. Always make sure to look around your vehicle and use your mirrors to confirm rearward clearance and that your vehicle can maneuver safely. Buyers Products Company and/ or its affiliates shall have no responsibility or liability for damage and/or injury resulting from accidents occurring with vehicles having some of Buyers Products Company products installed and Buyers Products Company and/or its affiliates, the manufacturer, distributor and seller shall not be liable for any in-jury, loss or damage, incidental or consequential, arising out of the use or intended use of the product. In no event shall Buyers Products Company and/or its affiliates have any liability for any losses (whether direct or indirect, in contract, tort or otherwise) incurred in connection with the systems, including but not limited to damaged property, personal injury and/or loss of life. Neither shall Buyers Products Company and/or its affiliates have any responsibility for any decision, action or inaction taken by any person in reliance on Buyers Products Company systems, or for any delays, inaccuracies and/or errors in connection with our systems functions.

Contact

If you have questions about this product, contact:

9049 Tyler Blvd. • Mentor, Ohio 44060 Phone (440) 974-8888 • Fax 800-841-8003 Email: support@buyersproducts.com www.buyersproducts.com

IN NO EVENT SHALL SELLER OR MANUFACTURER BE LIABLE FOR ANY DIRECT OR CONSEQUENTIAL DAMAGES OF ANY NATURE, OR LOSSES OR EXPENSES RESULTING FROM ANY DEFECTIVE PRODUCT OR THE USE OF ANY PRODUCT.

