



# INSTALLATION INSTRUCTIONS

**⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## APPLICATIONS

Make	Model
Honda	CR-V

## CUSTOM WIRING CONNECTOR



## WIRING LOCATION GUIDE

### SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S3 - Behind driver side rear access panel



## NOTICE

All steps must be followed to ensure the wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

- Ratchet
- 10mm socket
- Panel trim removal tool
- Clip removal tool

## ⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION / SAFETY INSTRUCTIONS

- Step 1**  
Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.
- Step 2**  
Open the vehicle tailgate. Remove storage area cover, rubber mat and spare tire cover (A).
- Step 3**  
Remove the D-rings on the driver and passenger sides. Remove the rear scuff panel (B).
- Step 4**  
Carefully pull back the driver side interior trim panel; a clip removal tool may be required. Separate the trim panel in the rear of the vehicle and work your way up and forward to locate the vehicle taillight wiring harness connectors. The connector will be similar to that on the custom connector (C).
- Step 5**  
Insert the custom wiring harness end into the vehicle harness connector. Make sure the connectors are fully inserted with locking tabs in place (D).
- Step 6**  
Route the remaining part of the custom connector behind the trim panel toward the rear of the vehicle.
- Step 7**  
Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape (E).
- Step 8**  
When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.
- Step 9**  
Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

